



## Silawrap NRF Instructions on McHale Fusion 3 Plus

### Instructions for use:

- Centre roll accurately when loading on baler for even coverage on bale
- Recommended maximum stretch for Silawrap NRF is 18%
- Apply a minimum of 3.5 turns of Silawrap NRF. This ensures a minimum of 2 layers of NRF on the bale
- Applying 4 turns will result in part of the bale being covered with 3 layers and part of the bale with 2 layers
- All settings can be adjusted with controller board

YOUR SILAWRAP TECHNICAL TEAM CAN BE CONTACTED AS FOLLOWS:

Factory / Office

IRL - 0539422985

INT - +353 539422985

[www.silawrap.ie](http://www.silawrap.ie)